



10	HF_DA
9	HF_DA
8	ERROR
7	ERROR
6	gnd
5	power_set_value
4	START
3	START
2	STOP
1	STOP

11	-24V
12	+24V
13	gnd
14	out_power
15	gnd
16	temp
17	gnd
18	B
19	A