



MMM, Mastersonic generators block diagram

Every incident overloading, over-voltage, short circuit and over-current on the load side will produce immediate generator STOP.

Realized by voltage and current measurements: Signal for any of overloading will stop the generator.